Box Style Wall Mounted Lockers
77704 Vented Door or 77714 Window Door
Assembly Instructions

Box style wall mounted lockers are fully assembled. The lockers should be placed in the installation location and anchored to the wall. The back of each individual box style wall mounted locker has four (4) key holes for mounting ease. Anchoring fasteners are not provided as individual job conditions will dictate the type of anchor fasteners that should be used.

SALSBURY INDUSTRIES
1010 East 62nd Street, Los Angeles, CA 90001-1598
Phone: 1-800-562-5377 Int'l Phone: 323-846-6700
Fax: 1-800-562-5399 Int'l Fax: 323-846-6800

Installation instructions are provided as general guidelines. It is advised that a professional installer be consulted. Salsbury Industries assumes no product assembly or installation liability.
Copyright © 2013 Salsbury Industries. All rights reserved. (Rev. 03, 5/6/2013) Page 1 of 1